



Instructions by Monster Shop (UK)

**Tambour Motorhome/Caravan Shower Door**

215336/215432

## Product Information

**Tambour Motorhome/Caravan Shower Door**

### Description

Intro description - The Tambour Shower Door is a space-saving solution specifically designed for caravans and motorhomes, offering both functionality and convenience in compact bathroom settings. Featuring a secure locking mechanism with a key, a magnetic catch for smooth closure, and a durable, flexible design, this door ensures privacy and ease of use on the move. Its lightweight construction makes it an ideal choice for enhancing comfort and efficiency in your mobile living space.

### Product specifications

	Dimensions
215336	200cm x 60cm
215432	200cm x 60cm

### SKU

215336, 215432

### Safety Advice

**Please read through the Safe Working Practice to ensure prevention of injury or damage to the device.**

- Ensure you have read and fully understood the instruction manual and safety advice before using this product.
- Operate the tambour shower door slowly and carefully to avoid pinching fingers in the sliding mechanism.
- Keep hands and fingers clear of the sliding mechanism while opening and closing the door.
- Regularly inspect the door tracks for any sharp edges and smooth them if necessary to prevent injury.



**Instructions by Monster Shop (UK)**

Tambour Motorhome/Caravan Shower Door

- Exercise caution when cleaning or handling the door to avoid cuts from sharp edges.
- Perform regular maintenance and cleaning of the door tracks to prevent obstructions that could cause jamming.
- In case of a jammed door, ensure there is an alternative exit plan from the shower area.
- Check that the door edges are properly sealed to prevent water leakage, which may cause a slip hazard.
- Wipe down excess water after showering to reduce the risk of slipping.
- Consider placing an anti-slip mat outside the shower area for additional safety.
- Avoid applying excessive force when operating the door to prevent breakage of plastic components.
- Periodically inspect the door for signs of wear and tear, and replace any damaged components as needed.
- Ensure that all components are securely installed and functioning correctly before use.
- If the door becomes difficult to operate, inspect the mechanism for dirt, damage, or misalignment and address any issues promptly.
- Only use this product for its intended purpose as a shower door in a motorhome or caravan.
- Keep children and pets away from the door while it is in motion to prevent accidents.
- Do not hang heavy items or apply unnecessary pressure to the door, as this may damage the mechanism.
- If any parts of the door appear broken or malfunctioning, discontinue use immediately and seek repair or replacement.
- If resizing or cutting the door, use appropriate tools and safety equipment, and ensure all edges are smoothed to prevent injury.

**Monster Group UK Limited's liability will be limited to the commercial value of the product only. Please visit <https://monstershop.co.uk/policies/terms-of-service> to see the full terms and conditions.**

## Parts

Shower Door Strips (Assembled)	1 piece(s)
-----------------------------------	------------

Embedded Tracks	4 piece(s)
-----------------	------------

90 Degree Track Connectors	2 piece(s)
----------------------------	------------

Keys	2 piece(s)
------	------------

Lock Catch	1 piece(s)
------------	------------

Screw Kit	1 piece(s)
-----------	------------



## Assembly

### Step 1 of 2

- Fit the Shower Door track pieces together until they make the completed unit.
  - Use the 90 Degree Track Connectors to fit the shape of the floor
- Secure them to the shower floor you wish to fit your door to
  - You can use adhesive or screws for this purpose
  - Adhesive is recommended for smooth door movement
- Repeat this process for the ceiling track ensuring that the two line up to guarantee a smooth sliding shower door

### Step 2 of 2

- Place the door panel in the gap between the floor track and the ceiling track making sure it runs between the two smoothly and doesn't catch
- Use the lock catch to secure the door in place during transit



## Maintenance & Troubleshooting

### 1. Maintenance

- **Regular Cleaning:** Wipe the door and track with a soft, damp cloth and mild detergent. Avoid abrasive cleaners that may damage the surface.
- **Inspect Mechanisms:** Periodically check the lock and magnetic catch for proper operation and ensure all parts are securely fastened.
- **Lubricate Tracks:** Apply a silicone-based lubricant to the door tracks occasionally to maintain smooth operation.
- **Check for Obstructions:** Ensure the track is free from debris or buildup that could hinder door movement.
- **Protect from Excessive Moisture:** While the door is water-resistant, avoid prolonged water exposure to the lock mechanism to prevent corrosion.
- **Ventilation:** After use, ventilate the shower area to reduce humidity and prolong the life of the door.

### 2. Troubleshooting

- **WHAT DO I DO IF THERE ARE MISSING PARTS FROM MY ORDER?**

If there appears to be any part missing from your order, contact our friendly and helpful Customer Support Team within 7 days of receipt.

- **FOR ALL OTHER ISSUES, PLEASE CONTACT OUR CUSTOMER SUPPORT TEAM.**



**Instructions by Monster Shop (UK)**

Tambour Motorhome/Caravan Shower Door